
General Risk Assessment

Disco Dome

Date of Assessment:	101/12/2017	Name of Assessor:		Gary MacAlister
Location of Assessment:		Approved by:		Hayley Bell
Affected:	Contractor	Staff	Visitor	General Public





Tel: +44(0)1225 765072

Risk Rating Matrix

All Risk Assessments must be written by a Competent Person. The Risk Rating should be determined using the matrix set out on the right. Hazards should be assessed before & after determining what the control measures will be. Once a final Risk Rating has been established the rules set out below must be applied.

> RISK Severity vs.

Likelihood

High

Medium

Medium

High

Medium

Medium

Additional Safety Information

Public Liability Insurance must be in place prior to using this equipment.

Staff should have access to first aid kit, mobile telephone & emergency contact details.

HAZARD	POTENTIAL INJURY / HARM
Inflatable moving / blowing away	Bruising, broken bones, head injury, unconsciousness, death
Equipment Failure – Damage whilst in use (users)	Entrapment, Bruising, broken bones, head injury, unconsciousness, death
Equipment Failure – Damage whilst in use (surroundings)	Entrapment, Bruising, broken bones, head injury, unconsciousness, death
Equipment Failure – Poor maintenance	Entrapment, Bruising, broken bones, head injury, unconsciousness, death
Instructors not following set-up instructions	Entrapment, Bruising, broken bones, head injury, unconsciousness, death
Diesel Generators	Burns, Fire, asphyxiation / diesel fumes

CONTROL	Residual Risk
All Inflatables should be anchored / pegged down during use at all times. Use all available anchor points on the equipment. At times when the wind is a significant hazard, then the activity should cease. (see manufacturers guidelines for recommended limits)	Low
All inflatable equipment must be visually checked prior to each use to check for defects or faults. If there are any concerns, the activity must not continue until the issue has been adequately fixed. This may mean cancelling the event if the fault has the potential to cause harm to users. Remove shoes and all sharp objects from users prior to use.	Low
The Disco Dome must be located on flat ground away from hot objects (fires / BBQ's), power lines, stones, gravel, broken glass or overhanging trees.	Low
All inflatable equipment should be checked annually in line with PIPA test recommendations (www.pipa.org.uk). Failure to undertake and record checks on equipment could lead to failure.	Low
All instructors must have received training on the set-up and use of the Disco Dome. All equipment must be set up in accordance with the instruction manual, and not adapted in any way in which to add additional risk to the activity.	Low
Diesel generators must be tested & serviced each year. Staff must be trained in the use of the generator. Diesel generators are only to be used in outside venues which allow natural ventilation of any fumes. Generator & blower must be located at least 1.2m away from the inflatable.	Low



Web: www.trowbridge.gov.uk Email: enquiries@trowbridge.gov.uk

HAZARD	POTENTIAL INJURY / HARM
Electrical Generator	Burns, Fire, Electrocution, electric shock, unconsciousness
Collision	Injuries caused to participants, Entrapment, Bruising, broken bones, head injury, unconsciousness, death
Slip, Trips and Falls	Injured Caused by falling over pegs, steps, power cables, Burns, Shock, Fire
Unsupervised use	Entrapment, Bruising, broken bones head injury, unconsciousness, death
Manual Handling	Back injury, muscle strain, sprains, hernia
Head Injury	Head injury, bruising, bleeding, unconsciousness, concussion
Falling from the inflatable onto the ground	Head Injury, bruising, broken bones, sprains, cuts.

RISK	Control
Severity vs. Likelihood	
Medium	Electrical generators must be Portable Appliance Tested (PAT) at least annually, possibly every 6 month if in heavy use. Visually inspect all wires and plug prior to use for any obvious signs of damage, and do not use if damaged. Only use inside, or outside in dry conditions. Use an RCD for protection.
High	To be manned by trained staff at all times. Maximum number of users as identified in the Disco Dome users instructions must be adhered to at all times. Rules to be clearly policed by staff, and users ask to leave if these are not being followed.
Medium	Cover any trailing wires with wire covers. Agree a safe route for wiring prior to use at large events or fetes. Do not block any emergency access routes or fire exits. Surrounding mats should be provided at the entrance to the equipment, and these must be in good condition.
High	If the Disco Dome must be left unsupervised at all, then it must be made safe so nobody can use it. This may include a barrier in the entrance or deflating the equipment and storing it away and left in a way that it cannot be turned on and used by anyone else.
Medium	The Disco Dome is heavy, and will require a mechanical aid or a 2 man lift to move from the van to the location of use. Do not attempt to move any heavy objects is they are beyond your personal limits. All staff should receive manual handling training on an annual basis.
Medium	The Disco Dome encourages users to be active & dance/bounce for fun. Any users that are causing any disruption or are becoming overly physical must be warned over their behaviour and failure to adhere to these rules will result in removal from the Disco Dome.
Medium	Ensure mats are placed around the entrance & exit locations of the Gladiator Joust to prevent injury if falling of the equipment.

Residual Risk Low Medium Low Low Low Low Low



Email: enquiries@trowbridge.gov.uk